



\*[EN] Use the stay (1 or 9) that matches the design of the existing stay mounted on the loader.

\*[SE] Använd det stag (1 eller 9) som matchar utseendet på befintligt stag monterat på lastaren.

\*[DE] Die Strebe verwenden (1 oder 9), das optisch zum vorhandenen, am Lader montierten Strebe passt.

\*[FR] Utilisez l'appui (1 ou 9) de même apparence que l'appui actuelle montée sur le chargeur.

M 4501225

---

**Part assemblies**      Support leg

---

<b>PartNo</b>	<b>Pos</b>	<b>Qty</b>	<b>Name</b>	<b>Specifications</b>
60021478-19	1	1	Stay	MF Red
60104308-19	2	1	Foot	MF Red
5002104	3	2	Screw	M6S M12X40 (8.8)
5002159	4	1	Screw	M6S M16 x 80 (8.8)
5011911	5	3	Nut	M12
5011569	6	1	Nut	
5002936	7	1	Screw	M6S 8.8 fzb M12 x 1,75 x 90
5021914	8	1	Spring	
60104233-19	9	1	Stay	MF Red