



r5212514\_5212524

---

**Part assemblies**      Bearing box

---

<b>PartNo</b>	<b>Pos</b>	<b>Qty</b>	<b>Name</b>	<b>Specifications</b>
5212514-3	1	1	Bearing box LH	Kubota Orange
5212524-3	2	1	Bearing box RH	Kubota Orange