





r20xxT_1

Part assemblies Loader beam

PartNo	Pos	Qty	Name	Specification
5211781-1	1	1	Loader beam w. bushings	Alo Black
5218004-1	2	2	Support leg	Alo Black
5214831-1	3	2	Link w. bushings	Alo Black
5214111-1	4	4	Link	Alo Black
5215219	5	1	Indicator rod	
5215208	6	1	Holder kit	
				
5215227	7	1	Spacer	
5013110	8	1	Washer	10.5x22x2
5050605	9	1	Screw	MC6S 10x50 Loc
5211255	10	1	Bracket	
5211256	11	1	Bracket	
5006001	12	4	Screw	MVBF 8x20
5011553	13	4	Nut	M6M M8 Loc-king
5013101	14	5	Washer	BRB 8,4 x 16
5215101	15	2	Cover	
5215021	16	1	Cover	
				
5011910	17	4	Nut	
5002058	18	1	Screw	M6S 8x16
5215191	19	2	Cover	
				
60018046	20	2	Pin	D=30, L=127mm. Replaces 9020034
				
60018053	21	4	Pin	D=35, L=127mm (9020035)
60018047	22	4	Pin	D=30, L=96mm. Replaces 9020037.
60018050	23	2	Pin	D=30, L=84mm. Replaces 9020039
5215131	24	16	Locking cover	
5050608	25	16	Screw	MC6S M10x20 Loc