



50020420

**Description** Nimco WK300  
**Part assemblies** Joystick

<b>PartNo</b>	<b>Pos</b>	<b>Qty</b>	<b>Name</b>	<b>Specifications</b>
5034359	1	1 PCS	Housing	
5034426	2	1 PCS	Pivot	
4500353	3	1	Pivot	
5034379	4	1	Locking plate	
5034380	5	1 PCS	Spring	
5034389	6	1 PCS	Steel ball	5 mm
5034381	7	2 PCS	Guide	
5034388	8	2	Screw	
5034417	9	1 PCS	Screw	M6 x 50
5034419	10	1 PCS	Washer	M6
5034418	11	2 PCS	Screw	M8 x 10
5034422	12	1 PCS	Washer	M14
5034382	14	1 PCS	Gaiter	L=165
5034414	14		Gaiter	L=103,5
5034386	15	1 PCS	Lever	
5034385	16	1 PCS	Handle	
5034387	17	2 PCS	Bushing	
60004236	13	2 PCS	Nut	M14 x 1.5