



**TO INSTALL LIFT ARM SUPPORT SERVICE:**

(1). RAISE THE LOADER LIFT ARMS COMPLETELY, STOP THE ENGINE AND REMOVE THE KEY.

(2). INSERT THE LIFT ARM SUPPORT DEVICE ONTO THE LIFT CYLINDER ROD.

(3). USE THE STRAP TO TIGHTEN THE SUPPORT DEVICE ONTO THE LIFT CYLINDER ROD.

(4). SLOWLY LOWER THE LOADER LIFT ARMS ONTO THE LIFT ARM SUPPORT. DO NOT POWER DOWN THE LOADER!

11136428


© 2025 Jost

| | |
|---|---|
| **Description** | L=510 mm |
| **Part assemblies** | Ram Stop Kit, long |

| PartNo | Pos | Qty | Name | Specifications |
|---|---|---|---|---|
| 4501259 | | 1 | Ram Stop Kit, long | |
| 60078974 | 1 | 1 | Mechanical Stop | |
| 5022145 | 2 | 1 | Tie-down strap | |


© 2025 Jost